

Manual / quick
reference guide

For Vacuvita Home Base,
vacuum containers and vacuum bags

vacuvita®

www.vacuvita.com

Welcome to the Vacuvita easy access storage system!

Keep food fresh and healthy

Vacuvita is based on a simple fact - when you remove oxygen, food stays fresh up to five times longer. Vacuvita is a fully-automatic vacuum food storage system. By removing air and storing food in an airtight environment you protect your food against humidity and other outside influences. Cookies and chips stay crispy, coffee beans keep their wonderful smell and fruits and vegetables retain their rich flavours. Placing food in a vacuum bag will prevent freezer burn, which is caused by dehydration and oxidation that occur when storing food in the freezer.

The Vacuvita easy access vacuum storage system is one of a kind. Just one touch is enough to release the vacuum immediately. The Vacuvita Home Base's lid will open by itself so you can access your food within seconds. The springs and dampers are perfectly balanced for smooth opening and one-handed closing of the cover. Creating a vacuum is as easy as closing the lid. Your Vacuvita system can be expanded to your fridge and freezer with our specially designed Vacuvita containers and vacuum bags.

Because Vacuvita is so versatile and easy to use, you will find yourself eating fresh foods more often.

Please carefully read this manual to ensure that you will use your Vacuvita products in the most effective and safe way and get the best results possible.





Important safety instructions

Please carefully read this user manual before using this product and keep it for future reference. When using your Vacuvita products, always take basic precautions, including the following:

1. Use the Vacuvita Home Base and vacuum bags only for their intended purpose, as described in this manual.
2. Do not use the appliance on wet or hot surfaces or near a heat source.
3. Place the device on a stable and flat surface. Caution: position the cord where it cannot be tugged, cause the user to become entangled, or cause the product to be overturned.
4. To protect against the risk of electric shock, do not immerse any part of the Home Base, power cord or plug into water or other liquids.
5. Always unplug the device before cleaning.
6. Never pull the cord to disconnect the Home Base from the outlet. Unplug the device by removing the plug itself.
7. Do not operate the appliance with a damaged power cord or plug. Do not operate the device if it malfunctions or is damaged. Contact us at service@vacuvita.com for the address of the nearest Authorised Service Center for examination, repair or adjustment. The device should not be serviced by the user.
8. Closely supervise children when using any electrical appliance. Do not allow the appliance to be used as a toy.
9. Do not use the Home Base outdoors

10. Do not put the Home Base in a refrigerator or freezer
11. Keep Vacuvita Home Base and other Vacuvita products and packaging away from animals and small children. There is a danger of suffocation.
12. Do not let the cable or adapter tube hang over the edge of a worktop, to prevent entanglement or tripping.
13. Do not use an extension cable.
14. Only use Vacuvita vacuum containers in combination with the Vacuvita Home Base. Using other vacuum sealers to create vacuum can damage the container.
15. Vacuvita container bases (but not the lids) are designed to be microwave-safe, however they are not intended for cooking. Do not use the containers in a conventional oven or under the grill.



Proper use

- Vacuvita Home Base and other Vacuvita products are not a substitute for refrigeration or freezing. Perishables still need to be kept in the refrigerator or freezer. Vacuum packaging is not a substitute for canning.
- Do not use any accessories other than Vacuvita accessories, as they are specifically designed to be used with our high performance vacuum equipment.
- During the vacuum packaging process or while using the vacuum adapter, small amounts of liquids, crumbs or food particles may be sucked into the adapter. Clean the adapter after each use. Regularly clean the filter of the Home Base.
- Avoid overfilling; never fill the vacuum bags or Vacuvita containers beyond the “maximum” fill mark.
- Do not change, adjust or mechanically alter the vacuum bags, or the sealing or valves of the Home Base or the containers. These products are manufactured with special care to guarantee best results and maximum safety. Tampering with these products may influence performance or result in injuries or damage.
- When vacuum packaging items with sharp edges (e.g. dried pasta or skewered products) in Vacuvita bags, protect the bag from punctures by wrapping items in soft cushioning material, such as a paper towel. You may want to use a Vacuvita container instead of a bag.
- **Important:** Do not store fresh onions, garlic, soft cheeses or mushrooms in Vacuvita Home Base or Vacuvita accessories.
- Beef may appear darker after vacuum packaging due to the removal of oxygen. This is not an indication of spoilage.
- When using a Vacuvita vacuum bag, make sure that the zip is properly closed before starting the vacuum process. Gently stretch the bag flat before closing the zip or using the vacuum adapter.



- Do not place crisp, dry foods and humid products in the same Home Base, container or bag. Moisture will migrate from the humid products to the dry ones and may cause them to turn soft or soggy.
- Foods with strong flavour and/or smell should be kept separately from other products to avoid transferring of their taste or odor to other foods.
- Some foods, such as tomatoes, saffron or pepper-based soups and sauces may cause staining of the plastic surfaces. This is not a malfunction and has no effect on the operation of the containers.
- Never use empty Vacuvita containers in the microwave. Never microwave the containers with the lid on to allow hot air to escape and prevent ruptures, damage to the container or injuries from exposure.
- You can heat cooked foods, such as leftovers, in a Vacuvita bag using a microwave. The bag should not be used to microwave raw foods. Always open the bag prior to putting it in a microwave to let the steam escape. Avoid microwaving foods containing oil, as it will get hot very quickly and could cause the side of the bag to stick together. Vacuvita vacuum bags cannot be re-used or re-sealed after being used in a microwave.

Content

Quick Reference Guide	8	Cleaning the dust and particle filter	17
The Vacuvita Home Base	8	Cleaning or replacing the removable air filter	17
The vacuum adapter and tube	9	Emergency vacuum release	18
Vacuum bags	10	Standby mode	18
Vacuvita containers	11		
System overview	12	Vacuum bags	
		Using the Vacuvita Home Base with vacuum bags	19
How to use your Vacuvita products	15	Cleaning the vacuum adapter	20
Prepare for use	15		
Home Base			
Using your Vacuvita Home Base	15		
Cleaning the Home Base	16		





Vacuum containers

Using the Vacuvita Home Base with vacuum containers 21

How to scan your containers: Using the QR code 22

Cleaning the container 23

Cleaning and re-installing the seal 23

Cleaning the valve 24

Troubleshooting 25

Storage chart 26

Food Safety Tips 29

Warranty

30

1 year Limited Warranty 30

What are the limits of Vacuvita's Liability? 30

How to Obtain Warranty Service 31



Quick Reference Guide

The Vacuvita Home Base

The Vacuvita Home Base is designed as a convenient and stylish stand-alone unit. It really is everything you need to get started.

 70°F	DO use with	DO NOT use with*
	Bread	Soup
	Rolls	Sauces / Marinades
	Cookies	Processed fruits and vegetables
	Cereal	Cooked meals
	Fresh fruits and vegetables*	Raw meats, fish, poultry
	Potato chips	Salads
	Coffee beans	Onions, garlic

* Foods that need to be kept at low temperatures should be stored in a Vacuvita container or vacuum bag. Fresh fruits and vegetables that can be kept outside the refrigerator, such as apples and peppers, can be stored in the Vacuvita Home Base.

Do not put the Home Base in the refrigerator or freezer. Always use proper food saving techniques to avoid food-borne illness. The Home Base is not intended for outdoor use.



Do not place crisp, dry foods and humid products in the Home Base simultaneously. Moisture will migrate from the humid products to the dry ones and may cause them to turn soft or soggy.

Do not allow water or liquids inside the Vacuvita Home Base. Do not submerge the Home Base in water.

For full instructions, see chapter 'How to use your Vacuvita products', page 15.

For a full list of products and preservation times, see chapter 'Storage chart', page 26 or www.vacuvita.com.

The vacuum adapter and tube

The vacuum adapter quickly and easily connects the additional storage units, such as the Vacuvita containers or vacuum bags, to the Home Base. This vacuum adapter allows you to use our external vacuum solutions for long-term storage in the pantry, fridge or freezer.

Simply connect the free end of the tube to the Home Base and place the adapter on the designated area of the Vacuvita container or vacuum bag. Just one touch to the capacitive touch button starts the vacuum process.

During the vacuum process small crumbs, food particles or drops of liquid may be pulled into the vacuum system. It is recommended that you regularly clean and thoroughly dry the adapter, especially after using it on bags containing liquids.

Do not attempt to detach the tube from the adapter.

For full instructions, see chapter 'How to use your Vacuvita products', page 15.



Vacuum bags

Vacuvida vacuum bags are BPA- and BPS-free and come in a variety of convenient sizes. Your Home Base comes with five medium-bags (2 quarts) and five large bags (1 gallon). More bags are available from the website and more sizes are coming soon!

Besides long-term storage, the bags are ideal for sous-vide cooking. This is a cooking technique that is based on the principle of slowly cooking your food under a vacuum in a temperature-controlled environment.



	DO use with	DO NOT use with*
 40°F	Marinated meats, fish, poultry	Cereal
	Hard cheese	Potato chips
 0°F	Deli meats	Leafy greens
	Fresh vegetables	Onions
	Coffee beans	Garlic
	Fresh fish	Mushrooms
	Fresh meat	Soft Cheese

* If you want to keep delicate products, such as potato chips and cereal, you can try one of the Vacuvida containers.

The bags can be opened and resealed, so it's very easy to use only one portion of the contents and store the rest away for a later time! Do not re-use the bags used for raw meats, fish or poultry. Always take proper hygienic precautions to prevent food-borne illnesses.

For more information on sous-vide cooking or a full list of products, visit www.vacuvida.com.

Vacuvita containers

Like the vacuum bags, the Vacuvita containers are free from BPA and BPS. The containers are microwave-, dishwasher- and freezer-safe and come in three different, stackable sizes (1 gallon, 2 quarts and 1 quart).

The containers are perfect for marinating. Marinating usually takes around 24 hours, but the Vacuvita system can bring it down to just 20 minutes! Vacuum helps to open up the pores of meat, fish and poultry, allowing the marinade to get absorbed more quickly.

Temperature	DO use with	DO NOT use with
70°F	Potato chips Cookies	Garlic Mushrooms
40°F	Nuts Raw pasta Fresh meat, fish poultry	Soft cheese Onions
0°F	Soup Sauces	

Always remove the lid before placing the container inside the microwave. The containers are suitable for storage at room temperature and inside your freezer or refrigerator.






Some foods, such as tomatoes, saffron or pepper based soups and sauces may cause staining of the plastic surfaces. This is not a malfunction and has no effect on the operation of the containers.

For a full list of products and preservation times, see chapter 'Storage chart', page 26 or www.vacuvita.com.

System overview

Vacuvida Home Base




1. Vacuvida Home Base
2. Easy Access control button, to automatically open the lid and release the vacuum
3. Blue indicator light
4. Home Base lid
5. Adapter socket (with removable cap)
6. Circular indicator LED light rings
7. Capacitive touch control to enable the “external vacuum” function

8. Emergency vacuum release switch
9. Air outlet with replaceable air filter
10. Power inlet


11. Lid seal
12. Dust and particle filter



Power adapter




13. 14V/1.5A Power adapter



- 14. Vacuum adapter
- 15. Detachable adapter lid
- 16. Adapter channel
- 17. Adapter ball
- 18. Adapter housing
- 19. Tube


Vacuvida Vacuum bags




- 20. 5 x Vacuvida bags; large
- 21. Re-sealable zip
- 22. Vacuum bag valve
- 23. 5 x Vacuvida bags; medium

System overview

Vacuvita Container



- 24. Container lid
- 25. Valve; socket for the vacuum adapter
- 26. QR tag
- 27. Container base with window




- 28. Recess for peeling seal from the lid
- 29. Seal inside the lid



How to use your Vacuvita products:


Prepare for use

- Remove all packaging and foils. Some parts of product packaging are eligible for recycling. Keep packaging away from small children.
- Position the Vacuvita Home Base on a flat surface with the lid closed. Place the plug from the power adapter into the socket at the back of the appliance and plug the other end of the power adapter into a power outlet.
- The circular indicator LED light rings on the top of the Home Base will briefly blink to indicate that the power is on.
- The blue indicator lights behind the control button will switch on and you will hear a short two-tone sound.
- You will hear the pump removing the air from the Home Base - the vacuum process has started.
- You can interrupt the vacuum process at any time by simply pushing the easy access control button to open the lid.
- Pressing the easy access control button releases the vacuum and opens the lid automatically.




Using your Vacuvita Home Base

- Open the Vacuvita Home Base by pressing easy access control button.
- There will be a brief sound of air being released and the lid will automatically open within a few seconds.
- Place your food inside the Vacuvita Home Base. For advice on proper storage of different types of food, see 'Storage chart' page 26.



Always allow food to cool to room temperature before applying the vacuum.


- Close the Home Base by gently pressing down the lid.
- When the lid is closed, the blue indicator light behind the control button will switch on and you will hear a two-tone chime.



- You will hear the air pump removing the air from the Home Base - the vacuum process has started.
- During the vacuum process, the pump may switch to a higher pump level up to two times. You will hear a slightly louder and higher pump sound. This is normal for the operation of the pump and does not affect the lifetime of the Vacuvita Home Base.
- After max. 90 seconds (depending on the fill level) the Home Base will reach its vacuum level and the pump will switch off automatically.
- Just as your refrigerator checks and adjusts its temperature when operating, the Vacuvita Home Base checks its vacuum level at regular intervals. At those intervals the pump will switch on to maintain the vacuum level in the Home Base.
- To open your Home Base again, just press the easy access control button. This may be done at any time while it is operating.


Cleaning the Home Base

- Open the Vacuvita Home Base by pressing the control button on the front.
- To protect against the risk of electric shock, cut the electric power by removing the plug from the power outlet.
- Clean both the outside and the inside of the Home Base using a sponge or cloth with water and mild soap.



Be careful not to flood the vacuum socket or air filter with water! Do not use the inside of the Home Base as a bowl for washing up. Do not submerge the Home Base in water!

- If required, the lid seal can be removed for cleaning. Gently pull it from the inside of the lid and use water and a mild soap.



Do not put the seal in the dishwasher.
Do not use sharp objects to remove or reinstall the seal.


- To re-install the seal, make sure it is positioned properly, with the solid section facing towards the inside and the two thinner flaps facing outside the Home Base.
- Gently press the seal in the groove, by first positioning the seal at the four corners and then pressing it down in the straight sections
- Be sure to press along the entire length of the seal, so that it is properly positioned and distributed evenly along the groove. Make sure not to stretch the seal during application.



Cleaning the dust and particle filter



During the vacuum process small crumbs or food particles may be sucked into the vacuum system. It is recommended that you regularly clean the filter on the Home Base.

- Place your finger in the slot on the filter.
- Simply pull the filter upward, sliding it out of the wall. Do not pull it towards you!
- Gently tap the crumbs and particles out of the filter.
- If the filter cannot be cleaned, replace it with an original Vacuvita part. Visit vacuvita.com for details.
- Gently slide the filter back after cleaning.



Cleaning or replacing the removable air filter

- Occasionally, you may need to clean or replace the air filter on the outside of the Home Base. It is recommended to clean the filter once every year, or when the pump sound is clearly louder and the vacuum process takes longer than prior.
- Remove the power plug from the wall socket. Place a soft cloth or towel in front of the Home Base.
- Gently tilt the Home Base forward, until the front touches the cloth. Do not drop the Home Base, as this may result in damage or malfunction!



If the filter cannot be cleaned, replace it with an original Vacuvita part. Visit www.vacuvita.com for details.

- Pull the filter from the bottom of the Home Base to clean it.
- Clean the filter by gently tapping it on a hard surface or use the corner of a clean cloth to remove dust and particles.
- After cleaning, push the filter back in place.
- Return the Home Base to its upright position and put the plug back into the wall socket.


Emergency vacuum release



Warning: In case of emergency, always remove the power plug from the wall socket.


In case of an emergency or system malfunction, the vacuum can be released by pressing the emergency vacuum release switch.

- Turn the Vacuvita Home Base, so the back is facing you.
- Using a thin product, such as a skewer, paperclip or needle, gently press the switch located behind the little hole in the Home Base housing.
- You will immediately hear the sound of vacuum being released.
- Keep the switch pressed until the sound has stopped
- Open the Home Base lid by pressing the button in the front, or open the lid manually.
- The Home Base is ready for normal use again.



has a standby mode. This standby mode allows the Home Base to open and close, but does not switch on the pump to create a vacuum.

- Close the Vacuvita Home Base lid.
- Place your hand on the lid as shown — there is no need to wait for the vacuum to be completed. Press down firmly.
- After five seconds, the blue indicator light on the front of the Home Base will begin to blink. Keeping your hand on the lid, press the control button on the front of the Home Base with your other hand.
- The blue indicator light will switch off; this means the standby mode is activated.
- If present, any vacuum will be released from the Home Base and the lid will open.
- Open and close the Home Base in the usual way. The blue indicator light and pump will not switch on when the Home Base is closed in standby mode.
- To switch off the standby mode, simply place your hand on the lid again and press. After five seconds, the blue indicator light will switch back on and blink.
- Keeping your hand on the lid, press the button on the front of the Home Base control button on the front of the Home Base with your other hand.




Standby mode

If the sealing is compromised, a vacuum cannot be created, or when there is no need or desire for vacuum storage, the Vacuvita Home Base




Using the Vacuvita Home Base with vacuum bags

- Use only Vacuvita vacuum bags. They are designed to be used with the Vacuvita high-performance vacuum system.
- Place your food item inside the bag. Always allow food to cool to room temperature before applying vacuum.
- Do not fill the bags beyond the maximum fill line, as food or liquids may be pulled into the vacuum adapter.
- Firmly press to close the zip completely.
- Place the bag on a flat surface, with the valve facing up.
- Remove the cap from the adapter socket behind the Home Base lid. Insert the free side of the adapter hose into the vacuum socket.
- The LED light rings will switch on, below the Home Base lid.
- Place the vacuum adapter on the marked area around the valve of the vacuum bag. Gently press it down.
- Press the capacitive touch control (the



middle of the area lit up by the LED light rings on the Home Base) to activate the vacuum process.

- Hold down the adaptor on the vacuum bag. The system will automatically switch off when it reaches the right vacuum level. Alternatively, you can stop the vacuum process manually by pressing the capacitive touch control.
- If there is still a lot of air inside the vacuum bag when it switches off, make sure the valve is not blocked by any food in the bag and repeat until the right result has been obtained.
- Remove the adaptor from the vacuum bag and disconnect the tube from the Home Base.
- If you wish, you can write down the date and contents of the bag in the designated area.
- Store your bag in a place that is appropriate to your food type and your intended preservation period (see also chapter 'Storage chart', page 26).




- To open, firmly grasp two sides of the bag near the zip and gently pull them apart.
- The bags are suitable for repeated use; just take out a portion of the contents and reseal as described above.




The bags are not intended to be cleaned. Do not use the bags for different (raw) products after each other. Always apply proper hygienic precautions to prevent foodborne illness.

- For an optimal vacuum process with liquids (such as freshly-made soup) we recommend placing the liquid in a bowl in the freezer for a few hours. Whenever possible, we recommend using our containers to store liquids. When the liquid has frozen, the vacuum process is the same as that with solid food.
- To store juicy, moist or marinated food, hang the vacuum bag from your kitchen worktop, keeping the valve flat on the surface. This will prevent the liquid from running into the valve and blocking the airflow.
- If liquids do enter the vacuum adapter the process will switch off automatically. Remove the adapter from the bag, clean it as described below and restart the process.



Cleaning the vacuum adapter

- Disconnect the adapter tube from the Vacuvita Home Base.
- Remove the lid from the adapter.
- Turn the adapter channel counterclockwise and lift it from the inside of the housing.
- Remove the ball.
- The parts may be cleaned using water and mild soap.



Do not scrub the sealing surfaces using scouring materials as this may damage the sealing and cause malfunctions. Make sure all the parts are dried properly before use, especially the inside cavities of the adapter housing.

Using the Vacuvita Home Base with vacuum containers

- Carefully follow the instructions on page 15 'Using your Vacuvita Home Base' to ensure safe use of the device.
- Place your food inside the container.






Always allow food to cool to room temperature before applying the vacuum.

- Do not fill the container beyond the max fill line, as food or liquids may be pulled into the vacuum adapter.
- Ensure that the seal in the lid and the rim of the container are clean and dry. Liquids and little pieces of food on the seal or the rim may prevent the container from reaching the appropriate vacuum level or cause leakage.
- Put the lid on the container and press firmly to close.
- Remove the cap from the adapter socket behind the Home Base lid. Insert the free side of the adapter hose into the vacuum socket.



- The LED light rings will switch on below the Home Base lid.
- Place the vacuum adapter on the valve and gently press it down.
- Press the capacitive touch control (the middle of the area lit up by the circular indicator light) to activate the vacuum process.
- Hold down the adaptor on the valve of the container. The system will automatically switch off when it reaches the right vacuum level.
- To open the container, release the vacuum by gently pulling up one of the flaps of the valve. You will hear a hissing noise that indicates that the air is now entering the container. When the hissing noise stops, open the lid as usual.



How to scan your containers: Using the QR code


All Vacuvita containers are equipped with a tag bearing a QR code. This helps you to easily identify the container and its contents, even if you have several containers in use.




You need the Vacuvita app to use the QR code – see [Vacuvita.com/mobile/app](https://www.vacuvita.com/mobile/app) for more information.

With the Vacuvita app, you can create an overview of the food stored in your freezer, pantry or refrigerator. The app will notify you when food is close to expiry so that it can be consumed while it is still safe, helping you to reduce waste and save money.

- After packing your Vacuvita container and completing the vacuuming process, scan the QR code, following the instructions on your mobile phone screen.
- The Vacuvita app will instruct you to fill in information such as the type of food in the container and where it will be stored (pantry, freezer or refrigerator).
- Place the container in the appropriate storage location.



- The app has added the container and its contents to the list of different foods that you have stored.
- If you have stored multiple containers in the same location (e.g. freezer), you can easily scan the QR code on the tags with the app to see what is inside.
- Next to the QR code, each tag also bears an alphanumeric code. The app displays this code in the list of stored food so that you can also find the container you are looking for without using the scanning function.



Cleaning the container

- Wash the container and the lid by using water and mild dishwasher soap.
- The base of the container is top-rack dishwasher safe. The lid should only be cleaned manually to avoid damage.




Do not scrub the seal or the valve using scouring materials as this may damage it and prevent the container from sealing

- Thoroughly dry the container and the lid before using it again.

Cleaning and re-installing the seal

- Flip the lid upside down. You will notice a small recess on the inner rim. Place your finger in the indent and gently pull out the seal.
- Clean the seal using water and a mild soap.





Do not put the seal in the dishwasher.
Do not use sharp objects to remove or reinstall the seal.

- Wipe the seal dry before re-installing it in the lid.
- To re-install the seal, locate the flat side of the seal. Keeping the seal flat side down, start by placing it one of the corners and pressing it down, working your way along the sides.

Cleaning the valve

- Grab the valve on top of the container by the flaps and pull it out of the lid.
- Clean the valve using water and mild soap.
- To re-install the valve, place it in the middle of the lid, aligning it to the indent. The nipple of the valve should go through the hole. Grab the nipple from the other side of the lid and pull it gently to secure it in place.



Troubleshooting

When the Home Base is unable to achieve the required vacuum level, either in the Home Base itself, the bags or the containers, one of the following light indicators codes may appear:

Lights are blinking		This means:	Possible solutions:
Inner LED light ring + Blue indicator light		The proper vacuum level in the Home Base cannot be reached. The system has automatically switched off.	<ul style="list-style-type: none"> • Check if there are any items sticking out of the Home Base that might prevent the lid from closing completely. • Check if there is anything crossing the seal. • If so, remove the items and try the process again.
Middle LED light ring + Blue indicator light		It takes too long for the proper vacuum level in the Home Base to be reached. The system has automatically switched off.	<ul style="list-style-type: none"> • Remove the lid seal and carefully clean it. • Closely inspect the seal for small damages, holes or ruptures. • If the seal is intact and clean, re-install it and try the system again.
Outer and inner LED light ring + Blue indicator light		The proper vacuum level in the container or bag cannot be reached. The system has automatically switched off.	<ul style="list-style-type: none"> • Check all connections between the Home Base and the container or bag. • Check if there are any items sticking out of the container that might prevent the lid from closing completely. • Check if there is anything crossing the seal. • Firmly press the lid back on the container and try again.
Outer and middle LED light ring + Blue indicator light		It takes too long for the proper vacuum level in the container or bag to be reached. The system has automatically switched off.	<ul style="list-style-type: none"> • Remove the container seal and carefully clean it. • Closely inspect the container seal for small damages, holes or ruptures. • If the seal is intact and clean, re-install it and try the system again. • Check the seal on the bag to see if it is properly closed. • Check if there are no holes or tears in the bag.
		This means:	Possible solutions:
Pump does not switch on + Light does not switch on		There is no electrical connection between the lid magnet and steel plate on the Home Base. The system did not switch on.	<ul style="list-style-type: none"> • Make sure the Home Base is properly connected to a power outlet. • Remove any items that might prevent the lid to close completely. • Clean the magnet on the lid and the steel plate on the Home Base. • Make sure the Home Base is not in standby mode. See page 18 for instructions regarding starting and stopping the standby mode.

In case the suggested tips do not help or the problem persists, please visit www.vacuvita.com or email us at service@vacuvita.com.

Storage chart

 70°F	Room temperature	No vacuum	Vacuum	Store in
	Baked goods	2-3 days	7-10 days	Vacuvita Home Base Vacuum bags Vacuvita container
	Bread, rolls	2-3 days	7-8 days	Vacuvita Home Base Vacuum bags Vacuvita container
	Coffee, tea	30-60 days	365 days	Vacuvita Home Base Vacuum bags Vacuvita container
	Cookies	120 days	300 days	Vacuvita Home Base Vacuum bags Vacuvita container

 70°F	Room temperature	No vacuum	Vacuum	Store in
	Dry foods	10-30 days	30-90 days	Vacuvita Home Base Vacuum bags Vacuvita container
	Nuts	30-60 days	120-180 days	Vacuvita Home Base Vacuum bags Vacuvita container
	Pasta (uncooked)	180 days	365 days	Vacuvita Home Base Vacuum bags Vacuvita container
	Potato chips	5-10 days	20-30 days	Vacuvita Home Base Vacuvita container
	Rice (uncooked)	180 days	365 days	Vacuvita Home Base Vacuum bags Vacuvita container



40°F	Fridge	No vacuum	Vacuum	Store in
	Cheese, hard	12-15 days	50-55 days	Vacuum bags Vacuvita container
	Cooked meals*	2 days	10 days	Vacuum bags Vacuvita container
	Desserts	5 days	10-15 days	Vacuum bags Vacuvita container
	Deli meats	3 days	6-8 days	Vacuum bags Vacuvita container
	Fish, fresh	2 days	4-5 days	Vacuum bags Vacuvita container
	Fruits, fresh	3-7 days	8-20 days	Vacuum bags Vacuvita container
	Lettuce	3 days	6-8 days	Vacuum bags Vacuvita container

40°F	Fridge	No vacuum	Vacuum	Store in
	Meat, cooked	4-5 days	8-10 days	Vacuum bags Vacuvita container
	Meat, fresh	2 days	6 days	Vacuum bags Vacuvita container
	Meat, sausages, smoked	90 days	365 days	Vacuum bags Vacuvita container
	Poultry, fresh	2 days	6 days	Vacuum bags Vacuvita container
	Spices, fresh	2-3 days	7-14 days	Vacuum bags Vacuvita container
	Vegetables, fresh	5 days	18-20 days	Vacuum bags Vacuvita container

Storage chart

0°F	Freezer	No vacuum	Vacuum	Store in
	Baked goods	6-12 months	18 months	Vacuum bags Vacuvita container
	Bread, rolls	6-12 months	18-36 months	Vacuum bags Vacuvita container
	Coffee, beans	6-9 months	18-27 months	Vacuum bags Vacuvita container
	Coffee, ground	6 months	12-34 months	Vacuum bags Vacuvita container
	Deli meats	2 months	4-6 months	Vacuum bags Vacuvita container
	Fish, fresh	6 months	18 months	Vacuum bags Vacuvita container

0°F	Freezer	No vacuum	Vacuum	Store in
	Fruit	6-10 months	18-30 months	Vacuum bags Vacuvita container
	Meat, fresh	6 months	18 months	Vacuum bags Vacuvita container
	Meat, minced	4 months	12 months	Vacuum bags Vacuvita container
	Poultry, fresh	6 months	18 months	Vacuum bags Vacuvita container
	Spices	3-4 months	8-12 months	Vacuum bags Vacuvita container
	Vegetables, fresh	8 months	24 months	Vacuum bags Vacuvita container

* Depends on ingredients.

For a full list, please visit www.vacuvita.com.

Food Safety Tips

Vacuum sealing fresh onions, garlic and/or mushrooms can lead to the growth of a species of bacteria that can cause botulism. Botulism is a very dangerous disease that can potentially be lethal, which is why we advise against storing these products in a vacuum when they are fresh. You can store cooked mushrooms, onions and garlic in Vacuvita bags or containers.

Soft cheeses can be a source of a species of bacteria called listeria that thrive under anaerobic conditions and can cause a possibly lethal infection called listeriosis. Due to this, soft cheeses should never be stored in a vacuum.

The vacuum packaging process extends the life of foods by removing most of the air from the sealed container, thereby reducing oxidation, which affects food's quality and flavor. Removing air can also inhibit the growth of microorganisms, such as molds and bacteria.

Illness-causing bacteria can grow in perishable foods within two hours. But by refrigerating foods properly, you can help keep food safe. You can significantly reduce the growth of microorganisms at temperatures of 40°F (4°C) or below. Freezing at 0°F (-17°C) does not kill microorganisms, but stops them from growing. Therefore, the long-term storage of perishable foods should be in the freezer or refrigerator.

It is also important to note that vacuum packaging is NOT a substitute for canning and it cannot reverse the deterioration of foods. It can only

slow down the changes in quality. It is difficult to predict how long foods will retain their quality because this also depends on the condition of the food on the day it was vacuumed packaged.

Use separate containers or vacuum bags for produce and for meat, poultry, seafood, and eggs. Placing ready-to-eat food inside a container that has held raw meat, poultry, seafood, or eggs can spread bacteria and make you ill. Preventing cross-contamination is simple. Use one container or vacuum bag for fresh produce and one for raw meat, poultry, or seafood. Before using them again, thoroughly wash containers and utensils that have been used to hold raw meat, poultry, seafood, or eggs. Vacuum bags are not intended to be cleaned after being used for raw meats, poultry or seafood.



Prevent cross-contamination by separating raw products from ready-to-eat foods.

Always thaw foods in the refrigerator or microwave – do not thaw perishable foods at room temperature.

Always take proper hygienic precautions to prevent food-borne illnesses.

For more tips and advice on food safety and preventing food-borne illnesses, visit www.foodsafety.gov.

Warranty

1 year Limited Warranty

Vacuvida B.V. (“Vacuvida”) warrants that from the date of purchase, this product will be free from defects in material and workmanship provided this product is used strictly as described in this user manual, using only original Vacuvida parts and accessories. This limited one year warranty shall be effective from the date of the original purchase and shall expire one (1) year after the original purchase date (“Limited Warranty Period”). Vacuvida, at its option, will repair or replace this product or any component of the product found to be defective during the Limited Warranty Period, provided the defect is not caused by the use of any non-Vacuvida branded part or accessory or has not been tampered with by others than Vacuvida personnel or service agents. A replacement will be made with a new or refitted product or component. If the product is no longer available, a replacement may be made with a similar product of equal or greater value. This is your exclusive Limited Warranty. Do NOT attempt to repair or adjust any electrical or mechanical functions on this product. Doing so will void this Limited Warranty. This Limited Warranty applies only to the original purchaser of the product and only from the date of initial retail purchase as per the original sales receipt and is not transferable. Proof of purchase is required to obtain warranty performance.

Vacuvida dealers, service centers, or retail stores selling Vacuvida products do not have the right to alter, modify or in any way change the terms and conditions of this Limited Warranty. This Limited Warranty does not cover ordinary wear and tear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper

voltage or current, use contrary to the operating instructions or this DFU, disassembly, repair or alteration by anyone other than Vacuvida or an authorized Vacuvida service center, or use of this product with non-Vacuvida parts or accessories. Furthermore, this Limited Warranty does not cover Acts of God such as fire, flood, hurricanes and tornadoes. This Limited Warranty shall not be deemed to exclude or replace any warranties set by law. Apart from the specific legal rights conferred to you in this Limited Warranty, you may have other rights which vary from jurisdiction to jurisdiction.

What are the limits of Vacuvida’s liability?

Damage to a product caused by use of non-Vacuvida parts or accessories, accident, misuse, or abuse is not covered by this Limited Warranty. Improper care and cleaning will void this Limited Warranty. Vacuvida shall not be liable for any indirect, incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition. Except to the extent prohibited by applicable law, Vacuvida disclaims all warranties, conditions or representations, express, implied, statutory or otherwise. Vacuvida does not claim the product to be fit for a particular purpose. Vacuvida shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including indirect, incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party. Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on





how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service

In the U.S.A.

If you have any question regarding this warranty or would like to obtain warranty service, please visit www.vacuvita.com or email us at service@vacuvita.com.

In the U.S.A., this warranty is offered by:

Vacuvita B.V.

Orionstraat 15

2516 AS The Hague

The Netherlands

PLEASE DO NOT RETURN YOUR PRODUCT TO THIS ADDRESS.

BO 4316

vacuvita®

Designed to suit your taste



Vacuvita B.V.
Orionstraat 15, 2516 AS The Hague, The Netherlands

www.vacuvita.com